

Procedure for ET-1000 update BMP files via DIGITA Network. Date: 20 Nov 2020



Version: 1.01

# **Application Note**

# **Procedure for ET-1000** update BMP files via Network.

Procedure for ET-1000 update BMP files via DIGITALVIEW® Network.



Version: 1.01

Date: 20 Nov 2020

#### **Revision History**

Date	Rev No.	Page	Summary
12 Oct 2020	1.00	All	First issued
20 Nov 2020	1.01	4	Update the ET-1000 Demo App V1.02 weblink
		8	Update the Pi OS image
			(pi_os_9_10_2020.img) weblink

Application Note:	Procedure for ET-1000 update BMP files via Network.	DIGITAL <b>VIEW</b> °		
Version: 1.01	Date: 20 Nov 2020			
Content:				

#### Content:

Procedure for ET-1000 update BMP files via Network 4	ļ
--	---

Procedure for ET-1000 update BMP files via DIGITA Network.



Version: 1.01

Procedure for ET-1000 update BMP files via Network:

\* Make sure the Wi-Fi or network(LAN) is connected to Raspberry Pi \*

Date: 20 Nov 2020

<Step 1> : Open the ET-1000 Demo App V1.02 which can be downloaded at :

https://drive.google.com/file/d/1765xQGe4XzbzAY9mo2uzrZVaB4gJZXHP/view?usp=sharing



Procedure for ET-1000 update BMP files via DIGITA Network.



Version: 1.01

Date: 20 Nov 2020

<Step 2> : Add or Drag bmp or jpg file (the 24 bits .bmp file must be used)



Procedure for ET-1000 update BMP files via DIGITAL Network.



Version: 1.01

Date: 20 Nov 2020

<Step 3> : Choose Slide show time interval, Panel Settings (31.2" / 42") and then choose 'Deploy via Network'.

	₩ ET-1000 Demo App V1.00 - 🗆 🗙
	Slide Show Time Interval (sec.) 10 Add File
	<b>DV2880x2160V.bmp</b> Size: 17.79 MB Date Modified: 2020-09-11 15:51:50
	Monsters.bmp Size: 17.79 MB Date Modified: 2020-10-09 11:41:56
	Panel Settings:     31.2"
	Enable 31.2" Flip Enable 31.2" Rotate 180°
~	Enable 42" Flip (Use 42" panel must be enabled, otherwise disable)
	Deploy via Network Deploy via Google Drive
5	Deploy via USB flash drive Control File Only
	DIGITALVIEW"



Procedure for ET-1000 update BMP files via DIGITA Network. Date: 20 Nov 2020



Version: 1.01

<Step 4> : Choose the corresponding Eink display to deloying the BMP image files.

DV	Discover Devices	×
DV	<b>DV-US-1</b> IP: 10.1.0.147 [ B8:27:EB:A0:C4:B5 ]	<
Canc	el Refr	esh

<Step 5> Enter the Password : 12345678 and change the new host name if you wanted. Then choose 'Deploy'.

DV	Deploy	-		×		
Enter the Pas	sword: ******* e password is wro connection will be	ong the fail.			<b>(</b> -	Password : 12345678
Enter the new	/ Host Name: DV-US-2				<u>ہ</u>	Can change the
Cancel		De	ploy			you wanted.



Procedure for ET-1000 update BMP files via DIGITA Network.



Version: 1.01

Date: 20 Nov 2020

<Step 6> : Deloying the files via network is in progress....

DV	Discover Devices	×
DV	<b>DV-US-1</b> IP: 10.1.0.147 [B8:27:EB:A0:C4:B5]	
Cancel		Refresh
Deploying		
	DIGITAL <b>VIEW</b> ®	

<Step 7> : The successful message will be displayed after deploying files completed.





Procedure for ET-1000 update BMP files via DIGITA Network.



Version: 1.01

Date: 20 Nov 2020

<Step 8> : New host name is updated.

DV	Discover Devices	×
DV	DV-US-2 IP: 10.1.0.147 [ B8:27:EB:A0:C4:B5 ]	
Cancel		Refresh

Please make sure you restore the the Raspberry Pi image by following the procedure shown in the following link :

https://www.howtogeek.com/341944/how-to-clone-your-raspberry-pi-sd-card-for-foolproof-backup/

And we have uploaded the Pi OS image (pi\_os\_9\_10\_2020.img) on Google Drive link :

https://drive.google.com/file/d/1qELnNPeUimG77QJYHGvbbnjHAe8pgrjM/view?usp=sharing

<END>

Application Not	te:
-----------------	-----

Procedure for ET-1000 update BMP files via DIGITALVIEW® Network. Date: 20 Nov 2020



Version: 1.01

#### **CONTACT DETAILS**

USA:	Digital View Inc.				
	18440 Technology Drive				
	Building 130				
	Morgan Hill, CA 95037				
	Tel: (1) 408-782 7773 Fax: (1) 408-782				
	Sales: ussales@digital	view.com			
EUROPE:	Digital View Inc.				
	Marylebone Passage				
	London				
	W1W 8EX				
	UK				
	Tel: (44) (0)20 7631 2	150 Fax :	: (44) (0)20 7631 2156		
	Sales : uksales@digita	lview.com	I		
ASIA:	Digital View Ltd.				
	Unit 705-708, 7/F Texwood Plaza				
	6 How Ming Street				
	Kwun Tong				
	Hong Kong.				
	Tel: (852) 28613615	Fax: (852)	25202987		

Sales: hksales@digitalview.com